


Installation, Operation and Maintenance

Watts® Home Mobile App



NOTICE

Watts is not responsible for failures due to connectivity issues, power outages, or improper installation.

WARNING



Please read carefully before proceeding with installation. Your failure to follow any attached instructions or operating parameters may lead to the product's failure.



Keep this Manual for future reference.



Table of Contents

Before You Begin.....	3
Legal	3
Download the Mobile App	3
Get Started	3
Create Account	4
Login.....	4
Locations - Create a Location	5
Locations - Standard and Custom Ordering	6
Locations - Edit Locations List.....	7
Away and Home Modes Toggle	8
Adding a tekmar® Device to Watts Home	9
Adding a SunStat® Device to Watts Home.....	10
Menu	11
Account & App Settings	11
Dashboard.....	12
Dashboard - Standard and Custom Ordering	13
Dashboard - Edit Devices List	14
Users	15
Setpoint Control	16
Models tekmar® 170	17
Thermostat	18
Models tekmar® 561 and SunTouch® SunStat®	18
Models tekmar® 562, 563 and 564.....	19
Snow Melting Control.....	21
Models tekmar® 670 and 671	21
Technical Data	23

Before You Begin

Legal

Before using the Watts® Home mobile application, you must agree to the Watts Terms of Use and Privacy Policy. These are available on the Watts.com website.

- <https://www.watts.com/terms-of-use>
- <https://www.watts.com/privacy-policy>

Download the Mobile App

The Watts Home mobile application supports both iOS and Android versions.

iOS: <https://apps.apple.com/us/app/watts-home/id1500497974>

Android: <https://play.google.com/store/apps/details?id=com.watts.home>

Get Started

Welcome to Watts Home!
On the welcome page, select “Get Started” button.



Create Account


Select “Sign up now” to create a Watts account.

Scroll down to the bottom of the Terms of Use and Privacy Policy and select the “Accept & Continue” button.

Enter your email address. This is used to create your Watts account.

To protect your identity, a verification code will be sent your email inbox. Please enter the verification code provided in the email into the app.

Lastly, please create a password.




Login

Click the “Sign In” button to login to the app using your Watts account email address and password.

To protect your identity, please keep your password secret and do not share with other users. Watts technical support will not ask you to share your password.

Watts uses Microsoft Azure for hosting the mobile app services. It is normal for a dialog box to appear asking if you wish to use watts.io to login.

If you forget your password, press “Forgot password.” A notification email will be sent to your account with a link to create a new password.





Locations - Create a Location


The app uses Locations to organize where your devices are installed and which users are able to view, change and receive information.

The locations shows the number of devices and users.

Selecting the location directs you to the dashboard for that location.

Press the ellipsis icon  to edit, delete or leave (if it is a shared location) a location.

To add a new location, click on the icon  located at the top right corner of the screen.




When creating a new location you can assign it to be the primary location, where you must have at least one location associated with your Watts Home account, and one of your locations must be designated as your primary location.

To create a location, enter the following information:

- Location Name
- Address
- Country
- State or Province
- City
- Zip or Postal Code

When you create a location, you become the location's "Owner." You can then share this location to other users.





Locations - Standard and Custom Ordering


Every user will have at least one location and in some cases may have several.

If you have two or more Locations, you can arrange them in either the “Standard Order (A-Z)” or create a customized list using “Custom Order.”


1. “Standard Order (A-Z)” shows Locations in alphanumerical order (1, 2, 3, ... a, b, c ...). You can personalize your order of Locations by pressing the “Standard Order (A-Z)” drop-down and choosing “Custom Order.”
2. Number of devices.
3. Shared location tile. The shared location tile does not display the number of users.
4. Number of users (only shown for a location that you are the Owner).
5. When Custom Order is active press “Edit Order” button to change the Locations order.



Locations - Edit Locations List



To rearrange your locations in the “Edit Locations List” mode, press and hold a location tile until its color changes, then drag it to your preferred position, or use arrow icons to move tile up or down




Pressing the “Save” button after updating your Locations order will display the updated order on the Locations page.

Away and Home Modes Toggle

The Away toggle saves energy by reducing the heating setpoints and increasing the cooling setpoints on your devices when the location is not occupied. For a snow melting control, selecting the Away toggle turns off the device, and as melting won't occur, this saves energy.

Press the away toggle to switch between home and away state.



1. "Away Mode" is enabled when the toggle is turned on.
2. "Home Mode" is enabled when the toggle is turned off.



Adding a tekmar[®] Device to Watts Home


Step 1

Select the Location that you want to add a device to.





Step 2

On your device, go to WiFi menu and press Register Device.




Step 3

Go the application's Dashboard screen and click on the icon  at the top right corner of the screen.



Step 4

Select "Add Device" from the bottom sheet.




Step 5

Enter the Device Code that appears on the device, enter a device nickname, then press "Add Device" button.

Adding a SunStat® Device to Watts Home


Step 1

Please choose the location within the Watts Home app where you'd like to add a new device.




Step 2

On the thermostat, go to Menu ≡ and select Settings ⚙ then Services (or Services & Voice) and choose the “Connect” button.




Step 3

Go to the application's Dashboard screen and click on the icon (+) at the top right corner of the screen.



Step 4


Select “Add Device” from the bottom sheet.




Step 5

Enter the Device Code that appears on the device, enter a device nickname, then press “Add Device” button.


Menu

Select the menu by pressing the BARS  icon.


The app version is listed at the bottom of the menu.



Account & App Settings



You can update your personal information by selecting Account




Select your notification and language preferences. Supported languages include English, Español, Français

Dashboard

The dashboard shows a list of all your devices.

Each device displays its nickname together with a summary of the device's status such as the device's temperature and operating mode.



1. To add a new device, click on the icon **+** located at the top right corner of the screen.
2. Location name and locations' drop-down list. Select the drop-down list to change the location.
3. Switch between Home and Away Modes using the toggle.




Dashboard - Standard and Custom Ordering

If you have two or more devices, you can arrange them in either the “Standard Order (A-Z)” or create a customized list using “Custom Order.”


1. “Standard Order (A-Z)” shows devices in alphanumerical order (1, 2, 3, ... a, b, c ...). This feature is enabled if you have two or more devices. You can personalized your order of devices by pressing the “Standard Order” dropdown and choosing “Custom Order.”
2. When Custom Order is active press “Edit Order” button to change the device’s order. This feature is enabled if you have two or more devices.



Dashboard - Edit Devices List



To rearrange your devices in the “Edit Devices List” mode, press and hold a device tile until its color changes, then drag it to your preferred position, or use arrow icons to move tile up or down.



Pressing the “Save” button after updating your device order will display the updated order on the Dashboard.


Users

When you create a location, you become the location's "Owner." You can then share this location to other users.

The location's owner can invite other users to join the location as either a "Contractor" or a "Guest." This could be a spouse, child or property caretaker.

Invited users will receive an email in their inbox with instructions to create a Watts account.

Once the invited user has accepted their invitation, their name will be listed on the location users screen.



Note: Both "Contractor" and "Guest" are considered a Shared User to the "Owner's" location, and both types have the same permissions in monitoring/controlling a device, as the "Owner's" location. Also, both types are restricted in not being able to add or delete a device from the "Owner's" location. As such, when inviting a Shared User, the classification of a Shared User as either "Contractor" or "Guest" is at the location's "Owner" discretion.

Setpoint Control

Models tekmar® 170


Background colors

Gray: not heating or cooling

Orange: heating

Blue: cooling

Heating setpoint




Go to device settings


Sensor temperature

Press Up or Down to adjust temperature

Setpoint Control



The Device Settings set the temperature units and Heat to Away setpoint or Cool to Away setpoint when in cool mode.



Indication that Freeze Protection has been enabled to prevent your system from freezing.

Thermostat

Models tekmar® 561 and SunTouch® SunStat®

The screenshot shows a mobile app interface for a thermostat. At the top, there is a blue header with a back arrow, a refresh icon, and a settings icon. Below the header, the text '1st Floor Thermostat' is displayed on the left, and 'Indoor 68 °F' is on the right. A tab bar below this shows 'Temperature' (selected), 'Schedule', and 'Usage'. The main area features a 'Schedule' toggle switch (turned on) and a large 'Heat to 70 °F' display with up and down arrows. Below this is a 'Thermostat mode' icon (a flame) and the text 'Heat mode'. At the bottom, there are two buttons: 'Cancel Schedule Override' and 'Save to Schedule'. Lines connect these elements to descriptive text on the left and right.

Background colors
Gray: not heating
Orange: heating

Heating setpoint

Save the temperature change to the schedule

Go to device settings

Indoor or floor temperature

Thermostat mode

Cancel the temporary override

Thermostat

Models tekmar® 562, 563 and 564


The image shows a mobile app interface for a thermostat. The interface is divided into several sections with corresponding callouts:

- Go to device settings:** A three-dot menu icon in the top right corner of the app's header.
- Indoor temperature:** The current indoor temperature, shown as 68°F.
- Heating setpoint:** The target temperature for heating, shown as 75°F.
- Cooling setpoint:** The target temperature for cooling, shown as 85°F.
- Thermostat mode:** A circular icon with a power symbol, labeled "Auto Mode".


Background colors are used to indicate the current state of the thermostat:

- Gray: not heating or cooling
- Orange: heating
- Blue: cooling


Thermostat




Enter the time and temperatures for your schedule.



When creating a new schedule, the days of the week can be grouped together.





Select Usage to view the weekly or monthly equipment run time.




The Device Settings set the temperature units, fan, relative humidity and floor setpoints.

Snow Melting Control

Models tekmar® 670 and 671




View current status of all sensors.



Select Usage to view the weekly or monthly equipment runtime.

Snow Melting Control

Device Settings ✕



Temperature Settings

Setpoints

Melting is the slab temperature when snow is detected. Idling and Storm pre-heat the slab to remove snow faster but at higher operating cost.

Melting Idling

Storm

Shut Down Setpoints

When it is warm outside, save energy by setting Warm Weather Shut Down (WWSD). Your installer sets the Cold Weather Cut Off (CWCO) based on the heating appliance's capacity.

WWSD CWCO

Enter the settings for your temperature setpoints, shutdown setpoints, runtimes, and temperature preference.

Device Settings ✕

When it is warm outside, save energy by setting Warm Weather Shut Down (WWSD). Your installer sets the Cold Weather Cut Off (CWCO) based on the heating appliance's capacity.

WWSD CWCO

Run Times

Set the Melt run times in hours and minutes.

Manual Melt Time

Sensitivity

Select the amount of water the sensor must detect to begin melting.

Sensor Setting

Device Preferences

Temperature Units

Scroll down to see all the settings. You must hit save for the settings to take effect.

Technical Data

Communications	WiFi 802.11n, 2.4 GHz, WPA2 encryption
Mobile app	Apple iOS 12 or higher, Android 10 or higher

Need help? Go to our website or contact us.

Watts.com/support/WattsHome

tekmarControls.com | tekmar.customerservice@wattswater.com | 1-800-438-3903

SunTouch.com | design@watts.com | 1-888-432-8932



USA: T: (978) 689-6066 • F: (978) 975-8350 • Watts.com

Canada: T: (888) 208-8927 • F: (905) 481-2316 • Watts.ca

Latin America: T: (52) 55-4122-0138 • Watts.com